



Instax Mini 90 Battery Removal

Prerequisite only

Written By: Nathan



INTRODUCTION

Prerequisite only

Step 1 — Battery



- The battery compartment can be found on the backside of the camera. Pinpoint this compartment and focus on the right edge of the compartment gate to find the opening latch.

Step 2



- Pinch the latch in towards the battery compartment gate. This will release the gate and allow it to open.
- Completely open the gate and remove from camera. Take out the battery and replace the gate.

This document was last generated on 2017-06-21 05:43:46 AM.